
INSTRUCTIONS FOR USE QUARTZ CHRONOGRAPH

MOVEMENT

ERBELIN

RONDA 10 1/2 3540-D





HANDS

- A. Hour hand
- B. Minute hand
- C. Seconds counter
- **D.** 1/10th of a second counter (hour counter after 30 minutes)
- E. Minutes counter
- F. Seconds counter
- G. Date

SETTING THE TIME

- 1. Pull the crown to position 3 (the seconds hand will stop)
- 2. Turn the crown until the correct time is displayed
- 3. Push the crown back into position 1

RAPID DATE CORRECTION

- 1. Pull the crown to position 2
- 2. Turn the crown in a counterclockwise direction until the correct date appears
- **3**. Push the crown back into position **1**

SETTING THE DATE AND TIME

Example:

- Date/time displayed on the watch: 25 / 10:10 AM
- Current date/time: 4 / 08:35 PM
 - 1. Pull the crown to position 2 (the watch will continue to run).
 - 2. Turn the crown in a counterclockwise direction until the day before the current date appears 3
 - **3**. Pull the crown to position **3** (the seconds hand will stop).
 - **4.** Turn the crown until the correct date 4 appears.
 - 5. Continue turning the crown until the current time, 8:35 PM is displayed.
 - **6**. Push the crown back into position **1**

CHRONOGRAPH, BASIC FUNCTIONS

- 1. Start: press push-piece (P1)
- 2. Stop: to stop timing, press push-piece P1 again and read the chronograph counters (**E**, **C** and **D**)
- 3. Reset: press push-piece (2) (The chronograph hands return to zero.)

CHRONOGRAPH, TIMING WITH TOTALIZATION

- (P1). Start: 1st push
 - Stop: 2nd push
 - A 3rd push restarts the stopwatch
 - The 4th push stops it, etc.
- (P2). Resetting the stopwatch

CHRONOGRAPH, TIMING INTERMEDIARY TIMES

- (P1). Starts the stopwatch
- (P2). 1st intermediary time
- (P2). To recover the time elapsed during reading and continue timing
- (P2). 2nd intermediary time, etc.
- P1). Stop
- P2). Reset

ADJUSTING THE HANDS AND THE CHRONOGRAPH IN POSITION O

Crown in position 3: press (P1) and (P2) simultaneously for 3 seconds

- (P1)*. Resets the seconds at the center
- (P2). Changes the hand
- P1. To change the 10th of a second (counter at 6 o'clock)
- (P2). Changes the hand
- (P1)*. To change the minutes (counter at 9 o'clock)
- 1. Normal position